Klima-Set Differential pressure switch for air

KS...C2

5.20





RoHS 2002/95/EG



Technical description

Two separate pressure chambers with pressure-side connection to hose nipples.

Each pressure chamber has a stepped connection of 6 mm dia. to 4 mm dia. Reference value (pressure difference) can be set directly. Reference value can be read off externally through the transparent hood.

Precise function through special switching system in a frictionless bearing. Contact switchover is performed when the set reference value is exceeded or undershot. Complete mounting kit enclosed.

Application

The equipment is used in ventilation and air-conditioning systems, DDC. It is specially designed for monitoring air ducts, filters, drive units and blowers.

Approvals

EC type test approval as per EC Gas Appliance Directive:

LGW C2 CE-0085 AQ 0693

Approvals in other important gasconsuming countries.

Functional description

Differential pressure switch in pressure and vacuum ranges. The differential pressure acts via the diaphragm against the force of the setting spring on the microswitch.

If the set reference value is exceeded or undershot, the circuit is switched on, off or over.

The differential pressure switch of the Klima-Set works without an auxiliary power.

DDC application

The switching contacts of the Klima-Set are made of gold-plated silver, for 24 V DC; 0.02 A.

When using the Klima-Set in conventional systems at 250 V AC, 5 A ohmic load, 3 A inductive load, cos φ 0.6, the gold-plated coating on the switching contacts burns off.

This makes a subsequent DDC application impossible.

Make sure that no condensate can enter into the pressure switch.lcing may occur at temperatures below zero which may lead to a malfunction or failure of the equipment.

Specifications

Max. operating pressure	50 mbar (5 kPa)				
Pressure connection	Hose connecting piece suitable for hose ø 4 / ø 6				
Temperature range	Ambient temperature Medium temperature Storage temperature	-15 °C to +85 °C -15 °C to +85 °C -30 °C to +85 °C			
Materials	Housing Switching part Diaphragms Switching contact	Polycarbonate Polycarbonate NBR gold-plated silver (Au), DDC applications: 24 V			
Switching voltage	Au contact	DC min. 5 V	max. 24 V		
Nominal current	Au contact	DC 20 mA			
Switching current	Au contact	DC min. 5 mA	max. 20 mA		
Electrical connection	On terminal screws via cable duct PG* 11 (* = heavy-gauge conduit thread)				
Protection type	IP 54 as specified in IEC 529 (EN 60529), optional IP 65				
Setting tolerance	±15% switching point deviation referred to reference value, adjusted as pressure rises, vertical diaphragm position, KS 150 C2 and KS 300/1 C2 adjusted as pressure falls.				

Klima-Set scope of supply

- 1. LGW...C2 differential pressure switch
- 2. Fixing bracket
- 3. Connection hose 4 x 1.5, 2 m
- 4. fixing screw
- 5. Drilling template for fixing bracket and hose connections
- 6. hose connection

Drilling template

- 7. Extension tube
- 8. Operating and assembly instructions

Accessories/Spare parts

see table on right Order No. 230 273 Order No. 230 303 (10 x) Order No. 230 304 (50 x) Order No. 230 305 (50 x)

Order No. 230 306 (50 x) Order No. 230 307 (50 x)


Hose connection

Fixing screws

www.dungs.com


Spare pressure switch for Klima-Set

For KS 150 C2 Order No. 217 778 For KS 300 C2 Order No. 217 779 For KS 300/1 C2 Order No. 224 389 For KS 500 C2 Order no. 226 327 For KS 600 C2 Order No. 217 780 For KS 1000 C2 Order No. 217 781 For KS 3000 C2 Order No. 217 782






Extension tube









Switching functions Switching difference Δp As differential pressure rises: 2 NO Setting tolerance 1 NC opens COM 2 NO closes As differential pressure falls: 1_{NC} 1 NC closes 2 NO opens The switching difference Δp is the pressure difference between the upper and

Schematic diagram Application and connection examples







Monitoring system vacuum

To monitor the pressure in vacuum systems.

Connect Klima-Set to the air duct via connection p2 (-).

Do not connect connection p1 (+) to the air duct.

Do not close the hose connection sleeve of connection p1 (+), a connection to atmosphere must exist.

Important: No dirt must enter into the equipment through connection p1 (+).

Filter monitoring

To monitor filter fouling, Klima-Set can be connected as shown above. Connection p1 (+) is connected upstream of the filter and connection p2 (-) downstream of the filter with the air channel in flow direction of volumetric flow.

Blower monitoring

lower switching pressures.

In the blower monitoring system, connection p1 (+) is connected on the pressure side downstream of the blower and connection p2 (-) is connected to the air duct upstream of the blower.

Always connect higher pressure to connection p1 (+).
Always connect higher vacuum to

connection p2 (-).

Example - System pressure Higher pressure:

e.g. 240 Pa: Connection p1 (+) Lower pressure:

e.g. 180 Pa: Connection p2 (-)

Example - System vacuum

Lower vacuum:

e.g. -130 Pa: Connection p1 (+) Higher vacuum:

e.g. -210 Pa: Connection p2 (-)

KS...C2



Brief technical data

1mbar = 100 Pa = 0.1 kPa \approx 10 mm WS 1 Pa = 0.01 mbar \approx 0.1 mm WS

Туре	Order No.	Measuring rar adjustable [Pa		Switching differ- ence Δp [Pa]	Max. operating pressure [kPa]
KS 150 C2	217 773	20 - 150	ļФ	≤ 18	5
KS 300/1 C2	224 390	20 - 300	↓Ū	≤ 20	5
KS 300 C2	217 774	40 - 300	† -	≤ 20	5
KS 500 C2	226 885	30 - 500	† [≤ 25	5
KS 600 C2	217 775	70 - 600	† ①	≤ 30	5
KS 1000 C2	217 776	100 - 1000	† @	≤ 40	5
KS 3000 C2	217 777	300 - 3000	† ①	≤ 80	5

Accessories Klima-Set	
Mounting kit display-LED 24 V yellow	231 774
Mounting kit display-LED 24 V green	248 240
Replacement set hood IP 54	230 270
Replacement set hood IP 65	230 271


Double adapter accessory kit


The double adapter permits the connection of additional service equipment, e.g. inclined tube pressure gauge.

Scope of supply of double adapter kit

2 double adapter 2 locking caps

Order No. 221 167





We reserve the right to make any changes in the interest of technical progress.

Head Offices and Factory Karl Dungs GmbH & Co. KG Siemensstraße 6-10 D-73660 Urbach, Germany Telephone +49 (0)7181-804-0 Telefax +49 (0)7181-804-166 Postal address Karl Dungs GmbH & Co. KG Postfach 12 29 D-73602 Schorndorf, Germany e-mail info@dungs.com Internet www.dungs.com